2025/09/08 10:21 1/5 Creality Ender 3 S1

Creality Ender 3 S1

Unboxing, assemble, initial leveling, print video: https://www.youtube.com/watch?app=desktop&v=Z2n3ATTNQpc&ab_channel=Pergear https://www.youtube.com/watch?v=AghQEvW-4JQ

Replacing Filament mid-print: https://www.youtube.com/watch?v=tCDtsEs51D8

Materials

Material settings: PLA 60C Hotbed, 200C Nozzle, for long narrow prints use 65-70C Hotbed temp ABS 100C Hotbed, 240C Nozzle, ensure no drafts during print

Warping on long models:

Set to 60 to 65 degree and im am cooling it down after first layer by 3-8 degree to 57°). Also tried reduce the temperature from the bed to 50-55 but Amazon Basic PLA (which is known for bed layer adhesion...) don't seem to stick well with this setting.

I reduced the fan speed and i enable the fan at layer 3 instead of 2 (also read that some people start fan at layer 5). This seems to work for now....

In general i would suggest to reduce bed heat as much as possible and maybe reduce the z-offset so that the first layer is literally pressed onto the bed. (Attention to not scratch your build plate) - (Check with first layer calibration prints which z-offset is the minimum to still have a nice first layer)

Webcam holder

Note that the standard webcam/tripod/camera mount screw is 1/4-20 UNC = 6.35mm with 20 thread size. An M5/M6 screw does NOT fit.

Ender 3 s1 Modular webcam mount by Taylorthomas https://www.thingiverse.com/thing:5414618

https://www.printables.com/model/328522-ender-3-s1-webcam-mount https://www.thingiverse.com/thing:5199333 https://www.thingiverse.com/thing:5349102 https://www.printables.com/model/273755-ender-3-s1-universal-webcam-mount Gantry Camera Mount for Ender-3 S1 by Superman889 https://www.thingiverse.com/thing:5476426 https://printingatoms.com/how-to-connect-camera-to-ender-3/

Ender 3 Raspberry Pi Camera Mount https://www.thingiverse.com/thing:3188580

Official Creality LED Light bar

https://www.amazon.co.uk/Creality-Official-3D-Printer-Upgrade/dp/B09VH3NMHP

The instructions are quite bad, so here are a couple pointers:

- It doesn't matter which LED power plug goes into the switch on the right hand side
- To screw it in, remove the blind plastic pieces at the top of the Z Axis
- for cable routing use the same path as the filament sensor cable. The blind snaps off and back on:

https://www.youtube.com/watch?v=LifRM4gGVi0

Ender 3 S1 Light Bar Cable Cover by kaimimue https://www.thingiverse.com/thing:5968849

S1/ S1 Pro parts

Bed screw locks https://www.thingiverse.com/thing:6070269/comments

Ender 3 S1/Pro extruder cable holder/guide by Bananenminister https://www.thingiverse.com/thing:5532813 https://www.printables.com/de/model/297182-ender-3-s1-pro-extruder-cable-holder-curaprofiles

Ender-3 S1 Easy Space Saver Control Mount - Easy Print (S1 Pro & V2 as well) *new version 1.02 link in notes by Zakor https://www.thingiverse.com/thing:5368309

Ender 3-S1 Tray Organizer Insert https://www.thingiverse.com/thing:5971430 or: Creality Ender 3-S1 - tray insert/Organizer By-N_G by N_G4ever https://www.thingiverse.com/thing:5499212

Needs to be printed in ABS, bottom part and motor cover: Ender 3 S1 Bed Cable Angle by MrPiouPiou https://www.thingiverse.com/thing:5417098 and remix of top part: Ender 3 S1 Bed Cable Angle by Phipsi12 https://www.thingiverse.com/thing:5531129/files About 1-2mm of overhang from the original connector needs to be removed to prevent the connector from catching the Z Axis motor.

Ender 3 S1 Flexible flat cable holder by Alei100 https://www.thingiverse.com/thing:5244810

Ender 3 S1 Cable Guide by chewduh https://www.thingiverse.com/thing:5754766

to check:

Ender 3 s1-things - Search

https://www.thingiverse.com/search?q=Ender+3+s1&page=25&type=things&sort=relevant

Ender 3 S1 Pro Filament Spool Clip by hayden-t https://www.thingiverse.com/thing:5418824

Ender 3 S1 - Torre de Temperatura - PRUSA Slicer by MatuKing https://www.thingiverse.com/thing:5418757

Bed Handle

Ender 3 S1 bed handle by DontKickTrees https://www.thingiverse.com/thing:5784354

Ender 3 S1 Handle for Bed by DevaZ https://www.thingiverse.com/thing:5746990

http://wuff.dyndns.org/ Printed on 2025/09/08 10:21

2025/09/08 10:21 3/5 Creality Ender 3 S1

Cable Chains

Ender 3 s1 cable chain by GreySid https://www.thingiverse.com/thing:5574037

Ender 3 S1 Pro Cable Chain by Selinuahs https://www.thingiverse.com/thing:5916206

Ender 3 S1 / Neo x Micro Swiss Direct Drive Cable Chain & right side carriage mount by hviet17 https://www.thingiverse.com/thing:5708954

Ender 3 S1 Pro - Heat Cable Chain by krebstiago https://www.thingiverse.com/thing:5800678

Ender 3 S1 Bed Cable Chain by Achaios https://www.thingiverse.com/thing:5834115

Ender 3 S1 Pro - Extruder Cable Chain by krebstiago https://www.thingiverse.com/thing:5800864

Bed Level Lock

Ender 3 S1/S1 pro - Locking Bed Level Knob by ajcam44 https://www.thingiverse.com/thing:5908385

Ender 3 S1 Pro Bed Level Lock by squat0001 https://www.thingiverse.com/thing:5903091

Bed Adjustment Wheel Clip by alei100 https://www.thingiverse.com/thing:5387968

Sensor mount

Ender 3 S1 and S1 Pro filament sensor bracket by mddatthngvrs https://www.thingiverse.com/thing:5419960

Sensormount - Creality Ender 3 S1 by jodill https://www.thingiverse.com/thing:5571665

Ender 3 S1 Filament Sensor Mount / Holder Rotated Version by joaolsneto https://www.thingiverse.com/thing:5332875

Ender 3 S1 runout sensor bracket by beefdrip https://www.thingiverse.com/thing:5905176

Display mount

Ender 3 S1 display bracket display mount by KennethBernal https://www.thingiverse.com/thing:5407497

Rotatable screen for Ender 3 s1 and s1 Pro by JohannBreid https://www.thingiverse.com/thing:5863301

Display Holder for ALL ender 3 s1 screens (knob and touchcreen) (Separate from printer) by HankTank109 https://www.thingiverse.com/thing:5626066

Last update: 2023/11/29 23:46

Sonic Pad

Enable root access: How to find the root password for Creality Sonic Pad:

- 1. Select "Other Settings" from the Creality Sonic Pad interface.
- 2. Select "Advanced Options"
- Select "Root Account"

root pw: cxsw-sonic 2023

root@spad-3858:/mnt/UDISK/printer_config# vi moonraker.conf

create .ssh/config entry and add something like the following

```
Host spad
HostName 192.168.1.13
Port 22
User root
HostKeyAlgorithms=+ssh-rsa
PubkeyAcceptedKeyTypes +ssh-rsa
```

Transfer ssh id to host either by editing/creating /etc/dropbear/authorized_keys or using copy_ssh_id

```
ssh-copy-id -oHostKeyAlgorithms=+ssh-rsa root@192.168.1.13
```

For OctoPrint, enable compat mode in moonraker.conf

Input shaping: Bracket holder STL files are on the provided usb stick.

https://m.youtube.com/watch?v=LGsbYTR7shk https://m.youtube.com/watch?v=TKInn-KMe9g https://m.youtube.com/watch?v=B zB5UHMZws https://m.youtube.com/watch?v=Kr2R5b8Z1y0

https://www.reddit.com/r/ender5/comments/122j285/placement of ender 5s1 sonic pad vibration g/

Cura and Klipper/Sonic Pad

https://all3dp.com/2/cura-klipper-tutorial/ - disable coasting in cura (interferes with klipper's pressure advance) - disable acceleration control and jerk control in speed settings tab - set Cura's retraction distance to 0.75 or 0.8 mm

Addons: arc welder moonraker connection

From:

http://wuff.dyndns.org/ - Wulf's Various Things

Permanent link:

http://wuff.dyndns.org/doku.php?id=3dprinter:ender3s1&rev=1701301567

Last update: 2023/11/29 23:46

